

Work Order ID 76411

76411

Page 1

November-14-11 10:32:48 AM

Item ID: D205-634-011

Accept

N900040100

Setup Start ***NS1***

Revision ID:

Item Name: Skidtube

Stop ***NS2***

Start Date: 14/11/2011 Start Qty: 1.00

1

Cust Item ID:

Required Date: 28/11/2011 Req'd Qty: 1.00

1

Customer:

Reference:

Approvals:

Process Plan: MLS

Date: 11/11/11 Tooling:

Date:

Run Start ***NR1***

QC:

Date:

SPC (Y/N):

Date:

Stop ***NR2***

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
--------------------------------	--------------------------	----------------------	---------	--------	--------------	---------------	---------------	------------------	----------------

Draw Nbr

Revision Nbr

IIN D205-634

Rev F

100

0.00

100

DC

Document Control

Memo

0.00

Photocopy bluefile & type labels per PPP D205-634-011
CHG 007

Switzloc

for MLS 11-11-30

110

Pick Kit

0.00

110

Packaging

Packaging

Memo

0.00

11/12/10 SP

120

QC4- 100% Inspect kits for completeness

0.00

120

QC

Quality Control

Memo

0.00

Switzloc

(H)

B76550

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries

Work Order ID 76411***76411***

Page 2

November-14-11 10:32:48 AM

Item ID: D205-634-011

Accept

N900040100Setup Start ***NS1***

Revision ID:

Stop ***NS2***

Item Name: Skidtube

Start Date: 14/11/2011 Start Qty: 1.00

1

Cust Item ID:

Required Date: 28/11/2011 Req'd Qty: 1.00

1

Customer:

Reference:

Approvals: Process Plan: _____ Date: _____ Tooling: _____ Date: _____

Run Start ***NR1***

QC: _____ Date: _____ SPC (Y/N): _____ Date: _____

Stop ***NR2***

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
130		0.00							
130									
Packaging	Memo	0.00							
Packaging	Identify and pack for shipping as per PPP D205-634-011								
	Location: _____								
	PPP rev: <u>9</u>								
140	QC21- Final Inspection - Work Order Release	0.00							
140									
QC	Memo	0.00							
Quality Control									

11/12/06

11/12/06

11-12-06

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries

Picklist Print

November-14-11 10:32:52 AM

Page 1

Work Order ID: 76411

76411

Parent Item: D205-634-011

D205-634-011

Parent Item Name: Skidtube

Start Date: 14/11/2011

Required Date: 28/11/2011

Start Qty: 1.00

Required Qty: 1.00

Comments: IPP Rev:P02.08.28Removed QC5 from Step 5KJ
IPP Rev:Q 08-08-12 now @ chg 006 (DSI 9417) DD verf:EC
IPP Rev R 09.01.28 now chg 007 DSI9417 revB EC verf:DD IPP Rev:S
10.12.01 as per chg008 DD verf:EC

Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Qty per Kit	Total Qty	Qty Issued	Date Issued	Status
D205-634-041		Manufactured	No			110	Each	4.0000	1	1			
D205-634-041									**				
Replacement Skidtube													

Location	Loc Qty	Loc Code
FG	-1	
56133	0	
56134	0	
56135	0	
56136	0	
56137	0	
56565	0	
56566	0	
FG073	5	
72092	1	
72290	1	
72859	1	
72860	1	

K10003

K10003

Saddle, D205-634-011

Manufactured No

110

Each

0.0000

1

**

B76502
11/12/10 SP

11-11-30

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries